



OLYMPUS PEN (ORIGINAL MODEL)




4 SCREWS FROM BEHIND
ATTACH SHUTTER TO BODY

"B" Lever



Flash Synch Contact



Shutter release



Timing gear return

